

# GEARBOX REPAIRING TOOLS



The tools are required for repairing the gearbox.

For 460plus (from SN 127522), 475plus (from SN 128912) and 490plus:

- LCA114617 and LCA114618 for gearbox of the gathering drum



For 475plus and 490plus:

- LCA114006 for gearbox of the cross feeding drum

